

# Tutorial on SCHOTT filter calculation tool

2015

Dr. Ralf Biertümpfel, April 2015

#### 1. Introduction

- 2. Properties of a single filter: transmittance and internal transmittance optical density an extinction
- 3. Comparing or Combining filters
- 4. Color of a filter (combination) and its light source
- 5. Tabulated data
- 6. User defined filters and light sources





### Intention of the calculation tool

#### **Overview on the functions of the Excel Spreadsheet**

- The calculation tool is intended to use for visualizing the optical reference values of our glasses. Internal Transmittance, Transmittance, Optical Density and Extinction data can be displayed as a function of wavelength and a desired thickness.
- > The internal transmittance data is listed from 200 nm to 5200 nm.
- Some values for the color analysis can be calculated as well.
- > The spread sheet offers the possibility to combine and compare several filters in respect to their optical properties.
- > The user may add spectral data of filter functions as a target.
- > The user may add spectral data for a user defined light source for color analysis.

#### Functions that are not present

- > This tool is not designed for optimizing the design process of an optical system.
- > The data base contains only typical transmittance data. There are no tolerances given in this tool.
- > This tool was composed with utmost care, however, there is no guarantee on the correctness of algorithms and data.



# Copyright © SCHOTT AG 2015

This calculation tool is protected by federal copyright law and international treaty. The copyright holder retains title to and ownership of the calculation tool. National copyright law prohibits you from making any copy of the calculation tool for any reason, without the written permission of SCHOTT, except that you may copy the contents of this calculation tool disc for your own research, teaching, and communications use.

Data and programs contained in this calculation tool are owned by SCHOTT, any request for permission to use them for commercial purposes must be directed to SCHOTT.

SCHOTT makes no warranty of representation, either expressed or implied, with respect to this calculation tool including their quality, merchantability, or fitness for a particular purpose.

In no event will SCHOTT be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the calculation tool even if SCHOTT has been advised of the possibility of such damages.

SCHOTT reserves the right to change the optical and non-optical data without prior notice. This calculation tool renders all previous versions of the tool obsolete and was composed with utmost care.

Mainz, April 2015



#### Language





#### Menus and Overview





#### 1. Introduction

2. Properties of a single filter: transmittance and internal transmittance optical density and extinction

- 3. Comparing or Combining filters
- 4. Color of a filter (combination) and its light source
- 5. Tabulated data
- 6. User defined filters and light sources





#### There are 9 sheets for analysis of a **single** filter







© SCHOTT AG

glass made of ideas

## **single** filter: transmittance and internal transmittance Transmissionsgrad und Reintransmissionsgrad



#### 1. Introduction

2. Properties of a single filter: transmittance and internal transmittance optical density and extinction

#### 3. Comparing or Combining filters

- 4. Color of a filter (combination) and its light source
- 5. Tabulated data
- 6. User defined filters and light sources





# Comparing / combining filters:





## Comparing filters: defining filter types and their thickness



glass made of ideas

**Multiple filters** 



### Comparing filters: diabatic, linear, normalized scale

# Combining filters: defining name and the components of the combination



**Multiple filters** 

## Combining filters: internal transmittance in diabatic, linear, normalized scale



#### 1. Introduction

- 2. Properties of a single filter: transmittance and internal transmittance optical density and extinction
- 3. Comparing or Combining filters
- 4. Color of a filter (combination) and its light source
- 5. Tabulated data
- 6. User defined filters and light sources





#### Color of light source and filtered radiation

- > All required data input for color analysis has to be given in the sheet "Data input" for a single filter.
- The user can choose any single filter glass type or the cemented combination of several filter glasses, which are given in the sheet "Data input" for "Combinations of filters."
- > The color of filtered radiation is a function of
  - the filter glass type
  - the filter glass thickness
  - the light source
- The color of a light source or filtered radiation can be described by the definitions of the CIE made in 1931 and 1976. The results are given as a graph or tabulated data



#### Color of filtered radiation in u'-v'-coordinates



Dr. Ralf Biertümpfel, April 2015 © SCHOTT AG

glass made of ideas

#### 1. Introduction

- 2. Properties of a single filter: transmittance and internal transmittance optical density and extinction
- 3. Comparing or Combining filters
- 4. Color of a filter (combination) and its light source

#### 5. Tabulated data

6. User defined filters and light sources





# The internal transmittance data is listed for the specified thicknesses

- > The sheet "CalcData" contains the internal transmittance data for the chosen filter types.
- The data is listed from 200 to 1100 nm in steps of 1 nm and from 1200 nm to 5200 nm in steps of 50 nm.

SCHOIT		Results of calculation of internal transmittance									
			Single filter	Calculation of a combination of filters							
Single filter				Target	Filter 1	Filter 2	Filter 3	Filter 4	Filter 5	Combination	
	Data input	filter glass type	UG5	UG1	UG5	UG11	BG64	Ti=1	RG780	Combi	
		Reflection factor P	0,910	0,910	0,910	0,910	0,916	1,000	0,910	0,920	
	CIE diagram	Reference thickness	1,00	1,00	1,00	1,00	1,00	1,00	3,00		
	CIE data table	Filter thickness d	2,000	1,000	0,900	1,200	1,000	0,000	0,000	3,100	
		λ[nm]	τι	τ <sub>i</sub> Target	τ <sub>i 1</sub>	τ <sub>i 2</sub>	τ <sub>i</sub> 3	τ <sub>i</sub> 4	τ <sub>i</sub> 5	$\tau_i$ combination	
	<u>Ti diabatic</u>	200	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	T diabatic	201	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	<u>Ti linear</u>	202	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	<u>T linear</u>	203	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	Extinction	204	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	Optical density	205	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
		206	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
		207	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
Combinatio	on of filters	208	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
	Data input	209	1,00E-10	1,00E-12	3,16E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,16E-19	
		210	4,99E-10	1,00E-12	6,52E-05	1,00E-06	1,00E-08	1,00E+00	1,00E+00	6,52E-19	
	<u>Ti diabatic</u>	211	8,47E-09	1,00E-12	2,33E-04	1,00E-06	1,00E-08	1,00E+00	1,00E+00	2,33E-18	
	<u>Ti linear</u>	212	9,91E-08	1,00E-12	7,05E-04	1,00E-06	1,00E-08	1,00E+00	1,00E+00	7,05E-18	
	<u>Ti normalized</u>	213	6,67E-07	1,00E-12	1,66E-03	1,00E-06	1,00E-08	1,00E+00	1,00E+00	1,66E-17	
		214	4,00E-06	1,00E-12	3,72E-03	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,72E-17	
		215	2,04E-05	1,00E-12	7,75E-03	1,00E-06	1,00E-08	1,00E+00	1,00E+00	7,75E-17	
User define	ed curves	216	1,19E-04	1,00E-12	1,71E-02	1,00E-06	1,00E-08	1,00E+00	1,00E+00	1,71E-16	
	Data input	217	4,37E-04	1,00E-12	3,08E-02	1,00E-06	1,00E-08	1,00E+00	1,00E+00	3,08E-16	
		218	1,12E-03	1,00E-12	4,70E-02	1,00E-06	1,00E-08	1,00E+00	1,00E+00	4,70E-16	
		219	2,28E-03	1,00E-12	6,47E-02	1,00E-06	1,00E-08	1,00E+00	1,00E+00	6,47E-16	
Results		220	4,76E-03	1,00E-12	9,01E-02	1,00E-06	1,00E-08	1,00E+00	1,00E+00	9,01E-16	
	Data table	221	8,97E-03	1,00E-12	1,20E-01	1,00E-06	1,00E-08	1,00E+00	1,00E+00	1,20E-15	
		222	1,64E-02	1,00E-12	1,57E-01	1,00E-06	1,00E-08	1,00E+00	1,00E+00	1,57E-15	
		223	2,72E-02	1,00E-12	1,98E-01	1,00E-06	1,00E-08	1,00E+00	1,00E+00	1,98E-15	
	Copyright	224	4,15E-02	1,00E-12	2,39E-01	1,00E-06	1,00E-08	1,00E+00	1,00E+00	2,39E-15	



#### 1. Introduction

- 2. Properties of a single filter: transmittance and internal transmittance optical density and extinction
- 3. Comparing or Combining filters
- 4. Color of a filter (combination) and its light source
- 5. Tabulated data
- 6. User defined filters and light sources







### The user may define his own filter glass types

- > The sheet "USER" has space for 100 different filter curves.
- > The internal transmittance has to be given in values ranging from  $0 < \tau_i < 1$ .

SCHOTT									
	User type name	V-LAMBDA	Mycurve	upper limit	linear				
	Reflection factor P	1,00	0,90	0,90	0,90				
Single filter	Reference thickness in mm	1,00	2,00	1,00	1,00				
Data input	Free for text and notes	380 - 780 nm	Example	Example	Example				
	λ[nm]	τ <mark>i 0</mark> 1	τ <sub>i 02</sub>	τi 03	τ <sub>i 04</sub>	τ <sub>i</sub> 05	τ <mark>i 06</mark>	τ <sub>i</sub> 07	τ <sub>i 08</sub>
CIE dia gram	200		0,001	1 1					
CIE data table	201		0,001	1	0,15075				
	202		0,001		0,1515				
<u>Ti diabatic</u>	203		0,001		0,15225				
<u>T diabatic</u>	204		0,001		0,153				
<u>Ti linear</u>	205		0,001		0,15375				
<u>T linear</u>	206		0,001		0,1545				
Extinction	207		0,001		0,15525				
Optical densit	208		0,001		0,156				
	209		0,001		0,15675				
	210		0,001	ļ	0,1575				
Combination of filters	211		0,001		0,15825				
Data input	212		0,001		0,159				
	213		0,001	ļ	0,15975				
<u>Ti diabatic</u>	214		0,001		0,1605				
<u>Ti linear</u>	215		0,001	ļļ.	0,16125				
<u>Ti normalized</u>	216		0,001		0,162				
	217		0,001	ļļ.	0,16275				
	218		0,001	Į	0,1635				
User defined curves	219		0,001		0,16425				
Filter	220		0,001		0,165				
Light source	221		0,001		0,16575				
	222		0,001	ļ	0,1665				
Results	223		0,001		0,16725				
<u>Data table</u>	224		0,001		0,168				
	225		0,001	ļ	0,16875				
	226		0,001		0,1695				
<u>Copyright</u>	227		0,001	Įl	0,17025				
	228		0,001	I	0,171				



#### The user may define his own light source

- > The sheet "user\_light" offers the possibility to define the spectrum of an own light source.
- The emissivity is normalized within the color analysis. Thus, the total intensity of the data input does not affect the results of color calculation.





## Addendum

- > Any comments or suggestions are welcome.
- > If you have any questions or recommendations please contact your local sales representative.

